

This exploded perspective view shows the front panel (10) and back cover (20) of the portable electronic device. The front panel (10) features a display area (12) composed of two sub-panels, 12a and 12b, which are shown being attached to the front face of the device. The back cover (20) is shown with a large array of circular openings, likely for ventilation or a speaker grille. Various other components are labeled, including a top bezel (25), a side bezel (26), a bottom bezel (27), and a rear panel (30). The device is shown in an exploded state to illustrate the assembly of these components.

FIG. 2




FIG. 3




FIG. 4